

## **“Two Minute Miracles” Stream Media from Your PC Through Your Game System to a TV**

---

*For many of us, PCs and laptops not only serve as our home office, but also store media such as our favorite music, homemade movies or pictures from family vacations. Instead of burning them to a DVD, there's a simpler way to display them on your living room TV.*

*In this “Two Minute Miracles” video, Agent Smith will show you how to wirelessly stream images or videos from your PC, through a game console to a TV.*

The following is a simple checklist of what's needed to wirelessly stream media:

- 1) A computer, either a laptop or desktop, with wireless capability and Windows Media Center
  - While Windows Vista Home, Premium or Ultimate is recommend, Windows XP with Media Center will also work but may require additional configuration
- 2) A wireless router
  - Check with your Internet provider, as many supplied broadband modems now include a built-in wireless router
- 3) A game console (ex. Xbox 360) with wireless capability
- 4) A TV connected to the game console

### **Configuring the Devices for Media Streaming**

- 1) Both the computer and game console must be connected to the wireless network before configuration
  - If you need assistance in setting up a wireless network, watch the following wireless connection video or call 1 800 GEEK SQUAD for support  
[Not All Wireless Standards Are Created Equal](#)
  - For increased streaming performance, the computer can also be directly connected to the network with an Ethernet cable
- 2) Enable the computer and game console to see and connect with each other
  - Launch Media Center on your PC, select “Tasks,” then “Settings” and finally, “Add Extender” (the Xbox 360 will be referred to as an “Extender” during setup)

- Before continuing the setup process on the computer, power on the Xbox 360. On the Xbox dashboard, select the Media blade (i.e. the blue one), then “Media Center”. Follow the on-screen instructions which will provide an eight-digit key
- Back on the computer, the Media Center Extender Setup will eventually ask for the Setup Key. Enter the eight-digit key from the previous step
- Select “Yes” when asked whether media should be shared with the Extender
- Enjoy all of your pictures from previous holiday get-togethers or your favorite holiday movie streamed and displayed on the fantastic plasma TV in the living room